

## StoQuik® Silver DrainScreen™ Floor Expansion Joint

Sheathing StoGuard® Waterproof Air Barrier Membrane Sto DrainScreen™ **Cement Board** Sto Base Coat and Mesh **Sto Primer** Sto Finish (smooth or textured) **Termination Accessory** Flashing StoGuard® Waterproof Air Barrier Membrane **Sto Joint Treatment** (Refer to Sto Detail 11.09 DS) **Closed Cell Backer Rod** StoGuard® Tape Floor Joist **Band Joist Wood Frame** 

## **Notes:**

1. Install closed-cell backer rod into sheathing joint to support barrier membrane.

Detail No.: 11.50 DS

Date: June 2011

- Install StoGuard® Tape so that it laps over StoGuard® below. Clamp the top edge of StoGuard® Tape with the flashing and shingle lap StoGuard® joint treatment over the vertical flashing leg.
- Refer to Sto Specification QS 200 DS for complete information on design require ments, installation and accessories.

IMPORTANT: Components not identified as Sto are furnished by other manufacturers and are not necessarily installed by trades who install the Sto products. Refer to project specific contract documents.

ATTENTION www.stocorp.com

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.

Property of Sto Corp. All Rights Reserved.