


## StoQuik® Silver DrainScreen™ Saddle Flashing

Date: January 2015

Detail No.: 11.65 DS



## Notes:

- Install StoGuard® waterproof air barrier membrane behind flashing assembly integrated with compatible roof or barrier membrane over the parapet.
- Install saddle flashing assembly.
  (Refer to Sto Detail 1.65b for Assembly of Saddle Flashing.)
- 3. Install Sto joint treatment over the top of the saddle flashing and back flange of starter track accessory. (Refer to Sto Detail 11.09 DS)
- 4. Lap cladding over the flashing assembly at the top a minimum of 2"(50mm) and terminate with 3/8" (10mm) joint around the perimeter.
- Refer to Sto Specification QS 200 DS for complete information on design require ments, installation and accessories.

IMPORTANT: Components not identified as Sto are furnished by other manufacturers and are not necessarily installed by trades who install the Sto products. Refer to project specific contract documents.

ATTENTION www.stocorp.com

Sto products are intended for use by qualified professional contractors, not consumers, as a component of a larger construction assembly as specified by a qualified design professional, general contractor or builder. They should be installed in accordance with those specifications and Sto's instructions. Sto Corp. disclaims all, and assumes no, liability for on-site inspections, for its products applied improperly, or by unqualified persons or entities, or as part of an improperly designed or constructed building, for the nonperformance of adjacent building components or assemblies, of for other construction activities beyond Sto's control. Improper use of Sto products or use as part of an improperly designed or constructed larger assembly or building may result in serious damage to Sto products, and to the structure of the building or its components.